

INTRODUCTION

The CALBOX-MB is a useful tool to configure and calibrate your Sensorex Smart Sensor (including modular sensors using the EM805 electronics module). It connects to your computer via a USB port and along with Sensorex software allows you to configure, calibrate and monitor sensor outputs.

Download software at:
<https://sensorex.com/product/sensorex-smart-sensor-user-interface-software>.



WIRING

Your Sensorex CALBOX-MB features quick connect spring terminals that hold wires firmly in place during setup. Press down to open and insert the color coded wires from your sensor as noted on the terminal block.

Wire Color	Function
Red	+V
Black	-V(gnd)
White	Modbus A(+)
Green	Modbus B(-)

Connect the wires from your sensor or S856 cable assembly to your CALBOX-MB as shown in FIG 1.

Your sensor or S856 cable should have wires colors as shown in FIG 2.



Products covered by this manual: S856 Cable assembly, S272CD-MA and -MB, ICTS3020, FCL-MA and MB, CLD-MA and MB, and DO64000-MB
 NOTE: Not compatible with Sensorex ODO series

Rev 2308.8