

GALVANIC DISSOLVED OXYGEN SENSORS

PRODUCT SPECIFICATION SHEET



Large solution capacity for long term deployment

Models with and without temperature sensor

Easy installation and maintenance

mV, 4-20mA and Modbus-485 outputs available

The DO6400 & 7400 series dissolved oxygen sensors feature a large capacity electrolyte holder, positive fit, easy to replace membrane and dependable galvanic cell technology for long term deployment. The body design ensures a good grip when wet. Ideal for Aquaculture and wastewater monitoring applications, these sensors require minimal maintenance. PTFE or High-Density Polyethylene (HDPE) membranes are available. 2 Replacement membranes, installation tool and electrolyte are included. Additional maintenance parts are in convenient kits (see ordering information). Sensors with mV output as well as built-in 4-20mA output in 0-100% and 0-200% saturation range are available. In addition, Modbus-485 output versions with 0-100% or 0-300% range are available.

SPECIFICATIONS

O2 Measuring Range	DO6400, DO64001C (0.5-20ppm), DO6441 (0-100%), DO6442 (0-200%) DO7400, DO7400TC (0.03-20ppm), DO7441 (0-100%), DO7442 (0-200%) DO6441-MB (0-100%), DO6442-MB (0-300%)
Rody Material	Nord

Body Material	Noryl
Cathode	Silver

Anode Zinc (DO6400 Series), Lead (DO7400 Series)

Maximum Temperature 50 Degrees C

12-36V DC (for Models DO6441, DO6442, DO7441 and DO7442 only) **Power Requirement**

(User specified temperature elements) Connect to your controller or PLC for temperature **Temperature Sensor**

output

Cable Length 10 feet, tinned leads Minimum Flow Rate 2 inches per second

Output @ Air Saturation HDPE DO6400 & DO7400 (45mV +/- 9mV)

PTFE DO6400 & DO7400 (33mV +/- 9mV)

HDPE & PTFE DO6441, DO7441 (0-100%) - fixed 4-4.5mA = <1 ppm DO, 18-22 mA = saturated air

HDPE & PTFE DO6442 - fixed 4 - 4.5mA = <1 ppm DO, 11-13mA = saturated air

PTFE DO6441-MB = 0-100% modbus 485

PTFE DO6442-MB = 0-300% modbus 485


PARTS COVERED BY THIS PRODUCT DATA SHEET INCLUDE: DO6400/H, DO6400/T, DO6440TC/H, DO6400C/T, DO6441/T, DO6442/T, DO7400/H, DO7400/T, DO7400TC/H, DO7400TC/T, DO7441/T, DO6441/T-MB, DO6442/T-MB

DO6400SPECS-12072023




Sensorex SUBMERSIBLE GALVANIC DISSOLVED **OXYGEN SENSORS**


OUTLINE DRAWING AND DIMENSIONS FOR DO6400 and DO7400 SERIES SENSORS



OUTLINE DRAWING AND DIMENSIONS FOR 4-20mA SERIES SENSORS



HOW TO IDENTIFY YOUR SENSOREX DISSOLVED OXYGEN(DO) SENSOR



DO6400SPECS-12072023



ORDERING INFORMATION

SENSORS		
Part No.	Description	
DO6400/H	DO Sensor, HDPE Membrane	
DO6400/T	DO Sensor, PTFE Membrane	
DO6400TC/H	Do Sensor, HDPE Membrane, supplied with customer specified temperature element	
DO6400TC/T	DO Sensor, PTFE Membrane, supplied with customer specified temperature element	
DO6441/T	DO Sensor, PTFE Membrane, 4-20mA (0-100% sat.)	
DO6442/T	DO Sensor, PTFE Membrane, 4-20mA (0-200% sat.)	
DO7400/H	DO Sensor, PTFE Membrane, (low range)	
DO7400/T	DO sensor, PTFE Membrane (low range)	
DO7400TC/H	DO Sensor, HDPE Membrane, (low range) supplied with customer specified temperature element	
DO7400TC/T	DO Sensor, PTFE Membrane, (low range) supplied with customer specified temperature element	
DO7441/T	DO Sensor, PTFE Membrane, (low range) 4-20mA (0-100% sat.)	
DO7442/T	DO Sensor, PTFE Membrane, (low range) 4-20mA (0-200% sat.)	
DO6441/T-MB	DO Sensor, PTFE Membrane, Modbus 485 (0-100% sat.)	
DO6442/T-MB	DO Sensor, PTFE Membrane, Modbus 485 (0-300% sat.)	
Note: 1) All DO sensors are shipped dry with membrane preinstalled 2) All DO sensors are shipped with 2 membranes,		
2 membrane O-rings, 1 membrane removal tool and 1 each 250mL of electrolyte (enough for about 6 refills).		



ACCESSORIES

Part No.	Description
DO6050/H	Membrane maintenance kit for DO6400 Series sensors: 5 each HDPE membranes, 5 each membrane O-rings, 5 each tensioning washer, 1 bottle (500mL) electrolyte, 1 body o-ring
DO6050/T	Membrane maintenance kit for DO6400 Series: 5 each PTFE membranes, 5 each membrane O-rings, 5 each tensioning washer 1 bottle (500 mL) electrolyte, 1 body o-ring
DO6051/H	Membrane maintenance kit for DO6400 Series: 25 each HDPE membranes, 25 each membrane O-rings, 25 each tensioning washer, 3 bottles (500ml ea) electrolyte, 5 body o-rings
DO6051T	Membrane maintenance kit for DO6400 Series 25 each PTFE membranes, 25 each membrane O-rings, 25 each tensioning washer, 3 bottles (500mL ea) elecrolyte, 5 body o-rings
DO6052	Spare Parts kits for DO6400 & DO7400 Sensors. Contains: 2 each membrane lock, 2 each tensioning washer, 2 each body o-rings, 1 membrane replacement tool
DO6054/T	25 each PTFE membranes, 25 each membrane O-rings
DO6054/H	25 each HDPE membranes, 25 each membrane O-rings
DO7050/H	Membrane maintenance kit for DO7400 Series sensors 5 each HDPE membranes, 5 each membrane O-rings, 5 each tensioning washer, 1 bottle (500mL) electrolyte, 1 body o-ring
DO7050/T	Membrane maintenance kit for DO7400 Series 5 each PTFE membranes, 5 each membrane O-rings, 5 each tensioning washer 1 bottle (500mL) electrolyte, 1 body o-ring
DO7051/H	Membrane maintenance kit for DO7400 Series 25 each HDPE membranes, 25 each membrane O-rings, 25 each tensioning washer, 3 bottles (500mL ea) electrolyte, 5 body o-rings
CALBOX-MB	Interface box for Modbus sensors to read output on computer

DO6400SPECS-12072023