



# **UVT-LED Sensor Installation and Operation Manual**





**UVT-LED-SW** 

Parts covered by this product instruction sheet include: UVT-LED-H, UVT-LED-SW, and all accessories and mounting hardware

11751 Markon Drive Garden Grove, CA. 92841 USA Fax +1(714) 894-4839

Ph +1(714) 895-4344

www.sensorex.com



### **Table of Contents**

1. Welcome	4
<ul><li>2. Getting to know your UVT Sensor</li><li>3. Warnings and Precautions</li><li>4. Introduction to UV transmittance (UVT)</li></ul>	4 <b>6</b> 7
<ul><li>5. UVT-LED Sensor Specifications</li><li>5.1 Operating Specifications</li><li>5.2 Dimensional Specifications</li></ul>	8
6. UVT-LED-SW 6.1 UVT-LED-SW sensor overview 6.2 First Time Setup and Preparation 6.3 Cleaning Procedure 6.4 Calibration 6.5 Taking Readings 6.6 Installation	11 12 13 14 14
Submersion In-line	15
a) Weld on Flange(UVT0009) b) 2" NPT Adapter (UVT0008, UVT0021) c) 3" Sanitary Tee (UVT0015), 2" Sanitary Tee (UVT0024) d) 2" PVC tee complete assembly (UVT0023)	19 20 21 22
6.7 Troubleshooting SW	23
7. UVT-LED-H	
<ul><li>7.1 Calibration</li><li>7.2Taking Measurements</li><li>7.3 Cleaning</li><li>7.4 Charging</li><li>7.5 Troubleshooting H</li></ul>	24 24 24 24 25



## **Table of Contents**

8. Ordering Information	26
9. Product Warranty	27




#### **Welcome to Sensorex UVT-LED!**

Thank you for choosing our UVT-LED UV-transmittance sensor.

For over forty years, Sensorex has been the preeminent supplier of leading edge technology and innovative products to measure and monitor the quality of water. Today, we remain focused on the continual advancement of water quality monitoring products and technology. The UVT-LED is the latest Sensorex innovation and our first optical-based measurement system designed specifically for simple, reliable UV-transmittance monitoring. The Sensorex UVT-LED is the world's first family of UV-T monitors that uses a UV-C LED instead of a mercury-based lamp as a light-source. The use of a UV-C LED in the UVT-LED ensures extremely stable readings in all conditions, over an extended lifetime.

### **Getting to know your UVT-LED Sensors**





## **Getting to know your UVT-LED Sensors (cont.)**



**UVT-LED-SW** 

Used for all open channel applications in which the unit is completely submerged, or in-line applications utilizing a 1.5" sanitary connection. Unit is wiped using patented technology. Use in water with a higher concentration of dissolved and suspended solids.



## Warnings



To avoid risk of damage to monitor, do not open the device. Refer servicing to qualified personnel only.



Do not use the provided power/data cord if it is damaged. Use of a damaged cord may result in damage to the device or fire.



Do not place device in a location near heat sources, or in a place subject to direct sunlight, excessive dust or mechanical shock.



Do not pinch the power/data cord between heavy objects



Do not operate sensor above 50°C because this can damage the UV Light source



Device should only be used with provided 24V DC power supply or used with a site supplied 24V DC source.



Monitor contains a UV LED emitting device. Do not look at the probe of an operating monitor without wearing proper eye and skin protection.



Install unit so that power cord is protected from mechanical damage and can be easily unplugged from device.



#### Introduction


UV-T is a measure of the amount of UV energy remaining after passing through a material (e.g., water sample or quartz) over a specific distance. UV Absorbance is a measure of the amount of UV light that is absorbed by a substance (e.g., water, microbial DNA, lamp envelope, quartz sleeve) at a specific wavelength (e.g., 254 nm). UV-Transmittance is related to UV Absorbance by the following equation (for a 1-cm path length): % UVT =  $100 \times 10^{-A}$ .

UV-Transmittance is typically;

- measured at 254 nm, corresponding to the peak output of mercury-based UV lamps
- measured over a path length of 1-cm
- represented as a percentage

UV-T has a strong effect on the dose delivery of a UV treatment system. As UV-T decreases, the intensity throughout the reactor decreases, which reduces the dose the treatment system delivers. UV treatment systems are sized to deliver the required UV dose under specified UV-T conditions for the application. UV-T will typically vary over time due to changing concentrations of compounds, seasonal effects and changes in biological activity of microorganisms within the water source.

UV-T monitors are commonly used as an input to a dose control strategy of a UV treatment system, helping to reduce over or under dosing. They are also used to monitor water quality to help diagnose operational problems.





## **Specifications**

**Measurement Technique:** UV absorption method (single beam technique), reagent-free

**Measurement Wavelength** 

/Pathlength: 254nm/1cm

**Measurement Range:** 10 -100% UV transmittance (UVT)

**Accuracy:** 1.0% T @ >50% T

Sample Flow Rate/

**Maxium Pressure:** n/a, 150psig

**Display:** LCD with LED backlight

**Measuring Interval:** 60 seconds (UVT-LED-SW only)

**User Maintenance:** 1hr/month typical

**Power Supply:** 20-28V DC, 5A, maximum 2000hm load, customer supplied (UVT-LED-PW & -SW)

24V DC to charge battery (UVT-LED-H)

Output: 0-100% UVT (UVT-LED-H-WD, UVT-LED-H-NA only), 4-20mA (UVT-LED-SW)

**Temperature Range:** 32-122 °F (0-50 °C)

UVT-LED-H - 0.78lbs (353g), UVT-LED-PW - 1.58lbs (717g), UVT-LED-SW **Weight:** 

-1.78lbs(807g)

Dimensions: 7.60"H x 2.60" cap x 1.25" probe (19.1cm H x 6.4cm Dia) - UVT-LED-H & -PW only,

9.4"H x 3.00" cap x 1.25" probe (23.9cm H x 7.6cm Dia)

IP Ingress Rating: IP66 housing, IP68 measurement head

**Certifications:** CE


Warranty: One Year Limited Warranty

Wetted Materials: SS316 body and wiper holder, PPS top cap, PTFE Wiper Blade



### **Outline and Dimensions**

#### **UVT-LED-H**






## **Outline and Dimensions(cont.)**

**UVT-LED-SW** 

Top View of 8-Pin connector O-rings to seal against UVT-SW-001, -002 or -003 Threads to attach UVT-I FD-SW cable 5.9" (150mm) using knurled nut 9.4" (239mm) Touch magnet provided to this surface to activate and calibrate the sensor 1.5" Sanitary Connection 3.5" (89mm) (31.8mm) 3.00" (76mm)

UVT-SW-001, -002, -003





#### Overview (-SW)

The Sensorex UVT-LED-SW is designed for use in both open channel/submersion UVT monitoring and in-line UVT monitoring of any type of water, including wastewater and drinking water. This patented UV-T monitoring device includes a UV-C LED light source, a UV sensor and wiper attached to a rotating measuring head.

It is operated by submerging the sensor mounted to installation hardware into a flowing water channel. The water sample flows through the measurement head, in between the UV light source and the UV sensor. The UV sensor measures the amount of UV light that the UV sensor is exposed to, measuring the amount of UV light that passes through the fluid sample. After the UV measurement of the water sample is collected, a quartz cylinder having a known UVT value is moved in between the UV light source and the UV sensor and another measurement is taken. By comparing the UV measurement taken through the quartz cylinder and the UV measurement taken through the fluid sample, a UVT value for the fluid is determined. In addition a third measurement is taken with the UV light source powered off providing a zero point calibration measurement for the UV sensor.

The sensor is calibrated by actuating with a magnet and placing in a sample of DI water. Measurements are taken by actuating the sensor again with a magnet and then measurements are automatic **every 3 minutes** and are output as 4-20mA scaled to 0-100% UVT.

When the quartz cylinder is rotated into a position between the UV light source and the UV sensor, a wiper, attached to the rotating mechanism, wipes the windows in between the UV light source and the water sample and the UV sensor and the water sample, thus removing any contaminants or buildup of constituents from the water sample on the windows. See FIG. 1. Note that UVT-LED-SW does not have a display but all other components match FIG 1.




### **First Time Setup and Preparation**

#### Step 1 - Unpacking your UVT-LED-SW


Make sure you have all parts in the box. Review the Packing List included in the product box for details. Your UVT-LED-SW sensor is supplied with an alcohol cleaning swab and a 10mtr cable (UVT-SW-001).


**Step 2: Cable Assembly Preparation:** A 10meter (33ft) cable assembly is included with each UVT-LED-SW. Assemble the cable to the 1" adapter of the UVT-SW mounting assembly. After the assembly is completely mounted then attach the sensor to the cable by aligning the connector parts and tightening the knurled nut clockwise until it stops (FIG 1). 1 inch of the cable jacket is stripped off for your convenience (see FIG 3). If you want longer leads, remove as much of the gray cable covering to reveal the length of wire you require. Next, strip the brown, white, and green wire tips to desired length and tin with solder to prevent wirings from fraying. Trim off braided shield and string filler even to cable jacket.



#### Step 3 - Powering your UVT-LED-SW

After the cable assembly has been connected to the UVT-LED-SW in step 2, wire the stripped end of the cable BROWN, WHITE, GREEN wires to your 4-20mA input device as shown in FIG 2 and 3.







### **Cleaning Procedure**

Cleaning with Deionized water is recommended every 30 days followed by recalibration off-line.

When fouling of the quartz windows are suspected, The Sensorex UVT-LED-SW should be cleaned according to the following procedure:

- 1) Remove Sensorex UVT-LED-SW from the process.
- 2) Fill up a small container with a 15-20% solution of phosphoric acid (e.g. Calcium Lime and Rust remover CLR) or food grade citric acid. Fill container high enough to completely submerge the measuring portion of the tip in the 15-20% solution of phosphoric acid or food grade citric acid (see FIG. 4).
- 3) While the unit is still powered, allow unit to soak for 30 minutes.
- 4) After 30 minute soak, rinse measuring tip with de-ionized water to rinse off excess cleaning solution.
- 5) Fill container with isopropanol, high enough to fully submerge measuring tip.
- 6) Submerge measuring tip in isopropanol for 10 minutes while unit is powered on.
- 7) Using the UVT-LED cleaning swab (part #UVT0011), gently clean the quartz measuring windows in front of the sensor and the UV-C light source.
- 8) Place unit in de-ionized water high enough to fully submerge measuring tip.
- 9) Submerge measuring tip in de-ionized water for 10 minutes.
- 10) Re-calibrate monitor according to recalibration procedure.

Fill all solutions above level shown with red arrow



FIG. 4



#### **Calibration**

Calibration should be done every 30 days after cleaning with deionized water. It is also recommended to verify sensor accuracy weekly using a hand-held UVT-LED-H sensor.

#### Step 1 - Place your UVT-LED-SW into de-ionized (DI) water.

Make sure it is inserted as shown in FIG 19 so that it is above the opening for the wiper and LED. Shake to remove air bubbles.

Step 2 - Hold Magnet over white dot sensor actuation location for at least 3 seconds as shown in

FIG 19. Wait for wiper to click. Remove magnet.

At completion of calibration, UVT-LED-SW will beep 7x.




FIG. 5

#### **Taking Readings**

Your UVT-LED-SW sensor will take readings every **3 minutes** after actuation of the wiper once the sensor is calibrated. You can take a reference reading at any time. To do this:

#### Step 1 - Place your UVT-LED-SW into a sample of your water.

Make sure it is inserted as shown in FIG 18 so that it is above the opening for the wiper and LED. Shake to remove air bubbles.

#### Step 2 - Hold Magnet over white dot sensor actuation location as shown in FIG 5.

Wait for 1 second. Remove magnet. UVT-LED-SW will beep 1x after reading is taken.



#### Installation


The UVT-LED-SW is designed for in-line and submersion mounting.

In abrasive solutions, install the sensor downstream of filtration to maximize sensor lifetime.

In-line mounting hardware for the UVT-LED-PW is also compatible with the UVT-LED-SW. Refer to pages 14-17 for in-line mounting options.

**Submersion mounting hardware options include:** 

- 1. UVT-SW-005: Complete installation kit that attaches to wall of channel. See below and follwing pages for instructions and FIGURE references.
- 2. UVT-SW-004: Retrofit installation kit that attaches to existing installation brackets from other suppliers that require 1 1/4" pipe. See FIG 32 for description of hardware.







FIG. 7





#### **Installation (cont.)**

#### 1) UVT-SW-005 step by step installation procedure:


- A) Attach provided steel 90 degree elbow to pipe with sealing tape or paste (see FIG 8
- B) Atttach 1.5" x 1" reducing fitting to elbow with sealing tape or paste (see FIG 9)
- C) Attach UVT-SW cable assembly to reducer (1" threads on both) and seal with sealing tap or paste. See FIG 10
- C) Feed cable up through pipe and insert into top cap/cord grip assembly. Make sure cord grip is loose when feeding cable through. See FIG11.
- D) Seal top cap onto pipe (make sure cord grip is loose). See FIG 12
- E) Tighten cord grip after applying some slack to cable. See FIG 13.
- F) Attach brackets x 2 to pipe. Make sure bolts are not too tight so the brackets can be adjusted up or down the pipe to the correct height and spacing. Spacing will depend on wall bracket height and distance apart.
- G) Attach wall mounting brackets to concrete wall in channel using customer supplied concrete anchor bolts. Note that assembly weighs 33lbs(15kg). Holes in wall mounting bracket are 0.65" (16mm) OD. See FIG 14
- H) Remove pins from brackets. See FIG. 15
- I) Slide pipe assembly onto the wall mounting brackets. See FIG. 16.
- J) Adjust pipe depth into water so that UVT-LED-SW measurement pathway is fully submerged.
- K) Tighten bolts on pipe clamps to hold in position.
- L) Reinstall locking pins into wall mount brackets. See FIG. 17
- M) To remove sensor for maintenance, remove the 2 locking pins and slide the pipe/assembly out of wall bracket channels.













## **Installation (cont.)**

2) UVT-SW-004: Retrofit installation kit that attaches to existing installation brackets from other suppliers that require 1 1/4" pipe. See FIG 18 for description of hardware.

Refer to FIG 22 - 27 for assembly procedure. After assembling, attach to existing clamps in place of 1.25" pipe from other supplier.




FIG. 18



#### In-line Installation

In abrasive solutions, install the sensor downstream of filtration to maximize sensor lifetime.

The UVT-LED-SW can mount into a few different installation types:

A) Weld on SS316 sanitary flange adapter (UVT0009) to pipe.

Weld #4 to pipe --> Install #2 into groove on top of #4 --> Insert #1 (UVT-LED-PW) into #4 --> Clamp in place with #3 by installing clamp around #4 and flange of #1, then tighten wing nut of #3 until tight and no leaking occurs. (see FIG. 19)




FIG. 19

11751 Markon Drive Garden Grove, CA. 92841 USA Fax +1(714) 894-4839

Ph +1(714) 895-4344







#### **Installation Cont.**

#### B) 2" NPT threaded adapter (UVT0008 - SS316, UVT0021 - PVC).

Apply threaded sealing tape or paste to threads of #4 --> Thread #4 into #5 (customer supplied) --> Install #3 gasket into groove of #4. --> Insert #1(UVT-LED-PW) into #4 --> Clamp in place with #2 by installing clamp around #4 and flange of #1 then tighten wing nut of #2 until tight and no leaking occurs (see FIG. 20). FIG 21 shows part detail.





Parts covered by this product instruction sheet include: UVT-LED-H, UVT-LED-SW, and all accessories and mounting hardware

FIG. 21

11751 Markon Drive Garden Grove, CA. 92841 USA Fax +1(714) 894-4839

Ph +1(714) 895-4344

sales@sensorex.com www.sensorex.com



#### **Installation Cont.**

C) 3" Sanitary tee kit (UVT0015) - refer to FIG. 12. 2" Sanitary tee kit (UVT0024) refer to FIG 22 Install #5 (x2) to grooves of #4 --> Install #6 (x2) to 4 with #5 (gasket) in-between --> Use clamp #7 (x2) to hold #6 (x2) to #4. Install #3 into groove on top of #4. Insert #1 into #4. Clamp #2 around #1 and #4 and tighten using wing nut of #2 until #1 is installed tightly (no leaks) into #4. Thread #8 (x2) into #6 (x2) using sealing tape or paste to avoid leaks. It is recommended to install this into a bypass loop with valves on each side of the assembly and a flow meter on the inlet side. See FIG 23.




FIG. 22




FIG. 23



#### **Installation Cont.**

D) 2" NPT PVC tee kit (UVT0023) - refer to FIG. 12

**Note:** Use sealing tape or paste on all threaded connections to avoid leaks.

Thread #6 (x2) into #5 --> Thread #7 (x2) into #6 (x2) --> Thread #8 (x2) into #7 (x2). Thread #4 into #5. Install #3 into groove on top of #4. Insert #1 into #4. Clamp #2 around #1 and #4 and tighten using wing nut of #2 until #1 is installed tightly (no leaks) into #4. It is recommended to install this into a by-pass loop with valves on each side of the assembly and a flow meter on the inlet side. See FIG 23. See FIG 24 for all parts inlouded in UVT0023. Suggested mounting orientation is shown in FiG 25.




FIG. 24




FIG. 25



## **Troubleshooting (UVT-LED-SW)**

3 beeps from sensor indicate a failure for the UVT-LED-SW. See chart below for faults and possible solutions.

Fault	Possible Solution
UVT-LED-SW will not switch on	<ul> <li>Check connections in power cabinet to ensure 24V DC is being supplied.</li> <li>Place magnet over white dot sensor actuation location and wait for wiper to actuate.</li> </ul>
UVT reading is lower than expected	<ul> <li>During measurement an air bubble may have been present in the measurement area. Ensure no air bubbles are present and repeat the measurement.</li> <li>Follow cleaning procedure to remove materials that may foul the sensor.</li> <li>Unit needs to be recalibrated accoring to outlined calibration procedure.</li> </ul>
UVT reading is higher than expectecd	<ul> <li>During calibration, an air bubble may have been present in the measurement area, Recalibrate unit.</li> <li>Follow cleaning procedure on page 20.</li> </ul>
UVT reading is not being transmitted to plant controls	- Check to make sure the 4-20mA signal loop has an external power source Ensure signal wires are connected per wiring diagram.
Analog scaling is not correct (-PW)	- Scaling should be set up for 4mA = 0% UVT and 20mA = 100% UVT.
UVT reading is ZERO	- During measurement an air bubble may have been present in the measurement area. Ensure no air bubbles are present and repeat the measurement.
	<ul> <li>Follow cleaning procedure.</li> <li>Recalibrate unit.</li> <li>LED or sensor has stopped working. Return for repair.</li> <li>Water has high absorbance and is not allowing UV-C light to pass through.</li> </ul>
Wiper Mechanism does not return to home position during cycle (-PW)	- Return sensor to supplier for repair/replacement.



### **UVT-LED-H**

#### **Calibration**

#### Step 1 - Place your UVT-LED-H into de-ionized (DI) water.

Make sure it is inserted as shown in FIG 26 so that it is above the opening for UV light source. Shake the sensor to remove bubbles. Remove from water and check for bubbles outside of the DI water. Re-insert into water if no bubbles are seen.

# Step 2 - Press and hold the "READ/CAL" button for at least 3 seconds as shown in FIG 27 (Make sure LOW BATTERY indicator is not on before taking measurement). See FIG 28

The display will flash blue 7x after calibrating. When the display reads >99.8%, calibration is complete. This should take approximately 10 seconds.







#### **Taking Meausurements**

#### Step 1 - Place your UVT-LED-H into the water sample you want to measure the for UVT.

Make sure it is inserted as shown in FIG 26 so that it is above the opening for UV light source. Shake the sensor to remove bubbles. Remove from water and check for bubbles outside of the DI water. Re-insert into water if no bubbles are seen.

**Step 2 - Reference measurment.** Press the **"READ/CAL"** button and release when the screen flashes 1x. This is done to ensure no bubbles are on the measuring surface.

**Step 3 -** When the **screen flashes 2x** then the sensor is ready to take a new reading **(new readings can only be taken 30 seconds after the previous reading)** 

Note: if sensor is not measuring for 10min, it will automatically turn off

#### **Cleaning**

Using the Sensorex UVT-LED cleaning swab (part #UVT0011) gently clean the quartz measuring windows in front of the sensor and the UV-C light source. Place unit in de-ionized water high enough to fully submerge measuring tip. Submerge measuring tip in de-ionized water tor for 10 minutes, according to recalibration procedure.

Charging Sensor - plug charging cable into sensor at connector at back of sensor. Charge for at least 2

hours when battery is discharged. When not in use, keep sensor attached to charger and plugged into wall.



# **Troubleshooting (UVT-LED-H)**

Fault	Possible Solution
UVT-LED will not switch on	- Check connections in power cabinet to ensure 24V DC is being supplied.
	- Check 5-pin connector on back of sensor to make sure it is securely attached.
	- During measurement an air bubble may have been present in the measurement area. Ensure no air bubbles are present and repeat the measurement.
UVT reading is lower than expected	<ul> <li>On battery-operated models, battery is low and unit should be plugged in to recharge battery. You can take measurements while UVT-LED-H is charging.</li> </ul>
	- Follow cleaning procedure on page 13 (-PW), 22 (-H) to remove materials that may foul the sensor.
	- Unit needs to be recalibrated accoring to outlined calibration procedure.
	- Make sure flow cell/pipe is full enough to completely submerge the measurement pathway. If not, adjust orientation.
UVT reading is higher than expectecd	- During calibration, an air bubble may have been present in the measurement area. Recalibrate unit.
	- Follow cleaning procedure.
	- Make sure flow cell/pipe is full enough to completely submerge the measurement pathway. If not, adjust orientation.
UVT reading is not being transmitted to plant controls (UVT-LED-PW ONLY)	- Check to make sure the 4-20mA signal loop has an external power source.
to plant controls (OV1-LED-PW ONLY)	- Ensure signal wires are connected per wiring diagram.
	- Check 5-pin connector on back of sensor to make sure it is securely attached.
Analog scaling is not correct (-PW)	- Scaling should be set up for 4mA = 0% UVT and 20mA = 100% UVT.
UVT reading is ZERO	- During measurement an air bubble may have been present in the measurement area. Ensure no air bubbles are present and repeat the measurement.
	- Follow cleaning procedure.
	- Recalibrate unit.
	- LED or sensor has stopped working. Return for repair.
	- Water has high absorbance and is not allowing UV-C light to pass through.
Wiper Mechanism does not return	- Return sensor to supplier for repair/replacement to home position during cycle (-PW).



**Ordering Information** 

Part Number	Description
UVT-LED-SW	Submersion Mount Process UV Transmittance Monitor (with wiper/auto cal.), includes 10m(33ft) detachable cable, cleaning swab
UVT-LED-H	Handheld, Off-Line Transmittance Monitor with power supply (outside of North America), case, cleaning swab x 1
UVT0001	Carrying Case for UVT-LED-H (included with UVT-LED-H-WD and UVT-LED-H-NA kits)
UVT0005	Worldwide Power Supply
UVT0006	North American Power Supply
UVT-SW-001	Detachable Power/Communication Cable for UVT-LED-SW, 10m (33 ft)- included with UVT-LED-SW
UVT-SW-002	Detachable Power/Communication Cable for UVT-LED-SW, 20m (66 ft)
UVT0011	Cleaning Swabs (pack of 50)
UVT0008	Installation Fitting, 2" NPT 316SS
UVT0009	Installation Fitting, Stainless Steel Pipe (requires welding)
UVT0015	Installation Kit, Sanitary Flow Cell (3")
UVT0021	Installation Fitting for PVC Pipe (2" NPT)
UVT0023	Installation Kit, PVC Flow Cell (2") with connections for barbed fitting with quick-disconnect
UVT0024	Installation Kit, Stainless Steel Flow cell (2") with 1/4" barbed fittings
UVT0025	1.5" Sanitary Flange Cap, Stainless Steel
UVT-SW-004	UVT-LED-SW Installation Kit, retrofit to other supplier installation kits that accept 1.25" diameter pipe.
UVT-SW-005	UVT-LED-SW Installation Kit, Complete



## **Product Warranty**

This UVT-LED product, as supplied and by Sensorex, or an authorized Sensorex distributor, and delivered new, in the original carton is warranted by Sensorex against manufacturing defects in materials and workmanship for a limited warranty period of:

One (1) year on all components

The limited warranty commences on the date of shipment. To make a warranty claim, the purchaser must contact Sensorex or distributor for problem determination and receipt of an RMA number. The serial number must be presented for warranty processing to begin.

Sensorex will repair, or replace, any part found to be defective, in our opinion and at no charge as stipulated herein, with new or reconditioned parts during the limited warranty period specified above. All replaced parts and products become the property of Sensorex and must be returned to Sensorex. Replacement parts and products assume the remaining original warranty, or ninety (90) days, whichever is longer.

This limited warranty covers manufacturing defects in materials and workmanship encountered in normal use of this product, and shall not apply to the following, including but not limited to: wear and tear to guartz window wiper blades, damage which occurs in shipment; delivery and installation; applications and uses for which this product was not intended; altered product or serial numbers; cosmetic damage or exterior finish; accidents, abuse, neglect, fire, water, lightning or other acts of nature; use in applications with water temperature and ambient air temperature over 100 degrees F, with water pressure greater than 150 psi (PW only); use of products, equipment, systems, utilities, services, parts, supplies, accessories, applications, installations, repairs, external wiring not supplied or authorized by Sensorex, or which damage this product or result in service problems; incorrect supply voltage, fluctuations and surges in electrical supply; customer adjustments and failure to follow operating instructions, cleaning and maintenance instructions that are covered and prescribed in the Operations and Maintenance manual.

There are no express warranties other than those listed and described above, and no warranties whether expressed or implied, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose, shall apply after the express warranty periods stated above, and no other express warranty or guaranty given by any person, firm or corporation with respect to this product shall be binding on Sensorex. Sensorex shall not be liable for loss of revenue or profits, failure to realize savings or other benefits, or any other special, incidental or consequential damages caused by the use, misuse or inability to use this product, regardless of the legal theory on which the claim is based, and even if Sensorex has been advised of the possibility of such damages. Nor shall recovery of any kind against Sensorex be greater in amount than the purchase price of the product sold by Sensorex and causing the alleged damage. Without limiting the foregoing, purchaser assumes all risk and liability for loss, damage or injury to purchaser and purchaser's property and to others and their property arising out of the use, misuse or inability to use this product sold by Sensorex not caused directly by the negligence of Sensorex. This limited warranty shall not extend to anyone other than the original purchaser of this product either from Sensorex directly or through an authorized Sensorex distributor, it is non-transferable and states the exclusive remedy.

Parts covered by this product instruction sheet include: UVT-LED-PW, UVT-LED-H, UVT-LED-SW, and all accessories and mounting hardware

11751 Markon Drive Garden Grove, CA. 92841 USA Fax +1(714) 894-4839

Ph +1(714) 895-4344

www.sensorex.com